



HAYMAN™
SAFE COMPANY

Minuteman

Series Gun Safe

OPERATION GUIDE



Minuteman Key Features:

- Secure Storage
- Fast Access
- Positive Control
- Discrete Appearance
- Muzzle Down Storage for Safety

IMPORTANT INFORMATION ABOUT YOUR SECURAM SCANLOGIC BIOMETRIC LOCK

The factory reset code **MUST** be changed and stored by the owner of the safe. The **factory reset code will reset the lock back to the default factory settings.** The Securam ScanLogic Basic operation manual (change factory reset code letter J) is included with the provided operation guide for advanced programming options.

The ScanLogic Basic is a very reliable and robust biometric safe lock system. This lock system allows for 3 unique levels of access.

1. The Manager level is the highest and controls all other levels.
2. The User 1 level can control this level and the User 2 level as well.
3. The User 2 level controls only this level.

All security levels have one unique code and 5 fingerprints associated with their respective levels. This means all locks will take up to 3 codes and 15 fingerprints. As the use of the minuteman gun safe is planned consider the benefit of utilizing all 3 security levels.

Figure1



Figure 2



Quick Start - Programming your Hayman Minuteman

Warning! Do all programming of the lock with the safe door OPEN!

A. Default Settings & Operation

1) The default manager code is set to 1 2 3 4 5 6. This code can be used to open the safe until it has been reprogrammed. No users can be added unless the manager code has been changed. Change the Manager code using the instructions below.

B. Change Any Code (Manager, User 1, & User 2)

1) Enter 0 0 0 0 0 0 (you will hear 1 beep per button push, and then you will hear 1 beep indicating programming mode)

2) Enter the existing code you wish to change, 1 beep acknowledgement will sound

3) Enter new 6 digit code, 1 beep acknowledgement will sound

4) Enter new 6 digit code again, 2 beep acknowledgement that code is changed

5) Verify your new code a couple times with the door open

**** 1 long beep means code is not allowed and a different code must be selected**

C. Add User 1

1) Open with Manager Code (Must have already been changed from 123456)

2) Press & Hold "1", until 1 beep acknowledgement

3) Enter new 6 digit code for User 1, 1 beep acknowledgement will sound

4) Repeat new 6 digit code for User 1, 2 beep acknowledgement will sound

5) Test new code for User 1 a couple times

D. Add User 2

1) Open with User 1 Code (as setup in step C)

2) Press & Hold "1", until 1 beep acknowledgement

3) Enter new 6 digit code for User 2, 1 beep acknowledgement will sound

4) Repeat new 6 digit code for User 2, 2 beep acknowledgement will sound

5) Test new code for User 2 a couple times

E. Add Fingerprint(s), any security level

1) Open with your code (Manager, User 1 or User 2)

2) Press & Hold "+", hold until 1 beep acknowledgement

3) Place fingerprint on reader, wait for 1 beep then remove finger,

4) Repeat step 3 for a total of 4 times with the same finger (position your finger at SLIGHTLY different angles each time, this will help the lock to recognize your finger in different positions)

4) 2 beeps confirm fingerprint addition was successful

**** each level can enroll up to 5 fingerprints, repeat this procedure for additional fingerprints.**

****It is recommended to enroll fingers from both hands**

F. Open safe with Fingerprint

1) Place finger on reader until 2 beeps sound & open door

G. Wrong Entry Penalty

Entry of four consecutive invalid codes results in a 5 minute penalty time period.

The unit beeps at 5 second intervals.

When time expires, 1 long and 2 short beeps sound.

Setting up of your Hayman Minuteman Series Gun Safe

The Minuteman Gun Safe is ready for one long gun up to 39", one sidearm, and one tactical device of your choice.

Long gun application:

Place long gun of choice on either side of the door, muzzle down with the magazine inserted. Place the muzzle on the foam pad on bottom plate and then strap the stock against the pad on the door. The firearm will lie on its side as pictured in figure 2. See Figure 1 for an example of use with a collapsible stock.

*Be sure to check the clearance of any optics on the firearm as a minor adjustment to the position of the Velcro strap at the top may be necessary to clear the door frame.

Sidearm Application:

Use the provided pistol pocket to place the sidearm on the door, muzzle down with the grip extending toward the intended user as pictured in figure 3.

*Depending on the profile of the long gun that is chosen to store on the door the configuration may vary. Make sure it is ergonomic and tailor the adjustments to the user's preference!

Figure 3



Adjustments can be made to the locations of the foam pad on the backside of the door, and to the plate on the bottom of the inside of the door to accommodate different firearm lengths as pictured in figure 1.

- To adjust the foam pad simply peel it away from the door and place it in a position that fits the profile of the selected firearm.
- To adjust the steel panel the muzzle rests on, lift the plate from the shelf track, and adjust it to fit the profile of the selected firearm.



HAYMANTM
SAFE COMPANY

SecuRam SafeLogic Toplit

Programming Guide



*SecuRam SafeLogic TopLit locks have two factory default codes.
A Manager Code of 1 1 1 1 1 1 and a Master code of 1 2 3 4 5 6.
All factory default codes **must** be changed before using your new safe.

To open your electronic lock, enter your 6 digit manager or master code.
The lock will beep twice indicating a correct code and the door can be opened.

If a wrong code is entered, the lock will beep three times indicating a wrong code.

If a wrong code is entered four times in a row, the lock will go into timeout mode for 5 minutes.

Wait for the timeout mode to expire and enter the correct code.

To change the Manager or Master code:

1. Write down your new code.
2. Open the door with the existing code.
Perform all code changes with the door open.
3. Enter 0 0 0 0 0 0 (lock beeps once).
4. Enter existing code once (lock beeps once).
5. Enter new code (lock beeps once).
6. Enter new code again to verify (lock beeps twice).

Test the operation of the new code twice before closing the door.

Lastly, test the operation of the new code with the door closed.

For more detailed information on your SecuRAM Safelogic lock visit

www.securamsys.com/safelocks/safelogic

Or for more information on these locks such as changing the batteries visit
YouTube and go to the HAYMAN Safe Co Network.



HAYMANTM
SAFE COMPANY

Limited Warranty

All Hayman Safe Company Minutemen Series Gun Safes carry a limited parts and labor warranty to the original purchaser to be free from defects in material and workmanship.

Minutemen Series Gun Safes are warranted for ONE (1) year from the original date of purchase.

This limited warranty applies only to new safes purchased from Hayman Safe, or an authorized Hayman Safe Dealer. Proof of purchase must be provided to establish the date of purchase. Hayman Safe Company's only obligations under this limited warranty are as follows: Hayman Safe Company, at its option, will repair or replace any defective part or unit and pay reasonable labor cost (once authorized). Under no circumstances will Hayman Safe Company be responsible for any consequential damages, incidental expenses, or personal injury of any kind (including, but not limited to, the death of any person or persons).

Authorization must be received from Hayman Safe Company before performance of any service which will be submitted under this limited warranty.

Improper installation, improper use, lack of proper maintenance, or accidental damage will void this limited warranty. This limited warranty cannot be changed, modified, enlarged or altered without direct written consent and written authorization from Hayman Safe Company.

HAYMAN SAFE COMPANY DISCLAIMS ALL OTHER WARRANTIES, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED, TO THE FULLEST EXTENT ALLOWED BY APPLICABLE LAW. NO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE SHALL APPLY EXCEPT AS REQUIRED BY APPLICABLE LAW.

HAYMAN SAFE COMPANY

1291 N County Road 426
Oviedo, FL 32765
www.HaymanSafe.com